

INDEX

I Istruzioni di montaggio e di assistenza
Specchio bifacciale

GB Installation and service instructions
Double-sided mirror

F Instructions de montage et d'entretien
Miroir double-face



D Montage- und Serviceanleitung
Zweiseitiger Spiegel

Dimensioni d'ingombro e quote di fissaggio


Overall dimensions and fixing points

Dimensions d'encombrement et fixations


Maßen und Befestigungshöhe




1




2




3



4



5



RIMOZIONE SPECCHI


How to move mirrors

Retrait de miroirs

Entfernung von Spiegeln


A

Lato 1 - Specchio piano diametro 200 mm.
Side 1 - Plane mirror, diameter 200 mm.
Côté 1 - Miroir plan diamètre 200 mm.
Seite 1 - Spiegelfläche, Durchmesser 200 mm.



B

Lato 2 - Specchio a 2 ingrandimenti diametro 200 mm.
Side 2 - 2 x magnifying mirror, diameter 200 mm.
Côté 2 - Miroir à 2 grossissements diamètre 200 mm.
Seite 2 - Spiegel mit 2 Vergrößerungen, Durchmesser 200 mm.



Pezzi di ricambio
Spare parts
Pièces de rechange
Ersatzteile

